Universal Media Interface (UMI)

Phone and USB Support Menus

UMI will default to Bluetooth if USB drive or iPOD is not connected.



TiWhen chosen the Bluetooth menu will display the options below.



Selecting Bluetooth settings will display all available options



If the Phone is paired the Phone name will be displayed on the screen



If call arrives the incoming number will be displayed on the screen



The screen will change and the call can be accepted by pressing ">>" tab



To reject a call or end a call press "<<" tab



When USB drive has been inserted the audio, with start immediately and the track name will be displayed on screen



Selecting Folder tab will display the directories and songs on the device



Navigate up and down with the up and down arrows for complete list



Selecting a folder the contents will be displayed



Universal Media Interface (UMI)

iPod/iPhone Support Menus

When iPOD is inserted select the iPOD tab to enter the iPOD mode.



The iPOD folder structure will be displayed



More folders can be displayed by selecting "^" arrow or "v" arrow



Selecting "Albums" will show all albums on iPOD.



When selecting an Album all tracks within the Album will be listed.



Read Track Name by pressing "-->" tab



Read Artist name by pressing "-->" tab



Read Album name by pressing "-->" tab



Read Genre by pressing "-->" tab



